CLEANING INSTRUCTIONS

If the pressure gauge on your filter reads 5 PSI or higher than the original starting pressure, the filter needs to be cleaned. The ClearWater II D.E. Filter System features the exclusive 1-2-3 Safety Locking System to ensure safe and simple filter maintenance.

- 1. Turn off pump. WARNING: Never attempt to clean filter while pump is running. This is a pressurized vessel. It could cause severe injury or harm to your person. Plug skimmer and pool return lines or drain pool water level to below pool return line.
- Slowly open the air release knob on top of filter until the pressure gauge reads "0". Open drain cap at bottom of filter and allow water to flow.

- 3. Press the yellow safety latch on the underside of the locking nut and turn the nut counterclockwise to remove the lid. Rinse the D.E. grids with a garden hose. There is no need to remove the element from the filter.
- 4. Reassemble lid and follow start-up procedures from original instructions.

Ny Original Starting Pressure is	_ PSI (Pounds per
guare Inch). I should clean the filter at	PSI.

LIMITED WARRANTY

Waterway Plastics manufactures its products and equipment in accordance with very high standards of workmanship. We use the best materials available and maintain the highest quality procedures practical in the industry. In accordance, Waterway warrantys its products as follows:

All plastics parts such as jets, valves, skimmers, manifolds, suctions, lights, and other plastic components manufactured by Waterway will be replaced or repaired, if the defects are determined by Waterway to be the responsibility of Waterway Plastics, for a period of three years from the date of installation. The warranty does not cover filter cartridges, D.E. grids, O-rings, pressure gauges, pump seals, light bulbs or any parts not manufactured by Waterway. Warranty applies to OEM's and Distributors of Waterway Products.

The Supreme and Hi-Flo Pumps will receive limited warranty from any defect in material or workmanship for one year from the date of manufacture. This includes the motor but not the motor seal.

All thermoplastic molded filter bodies and rotational molded sand filter bodies have a warranty of ten years, warranted on a pro-rata life basis. If a defect becomes apparent during the first year, the body will be exchanged for a new body if the defects are determined by Waterway to be the responsibility of Waterway Plastics. If a defect becomes apparent after the first year from the date of manufacture which, in the opinion of Waterway, will require

replacement, the body will be exchanged for a new tank on an adjusted service pro-rata life basis. Charges to the owner, on the pro-rata life basis, will be determined by the actual number of months installed beginning with the date of installation.

Products that fail or become defective during the warranty period, except as a result of improper installation, bad water chemistry, accidents or negligence on behalf of the owner, freezing, earthquakes, fire floods, or other acts of nature, shall be repaired or replaced at Waterway's option without charge to the owner. This process will be completed within 90 days of receipt of the defective product barring delays caused by the acquisition of component parts not manufactured at our facility.

To obtain warranty replacements or repair, defective products should be returned (transportation paid) to the place of purchase, or to Waterway. It should include a description of the defect and the circumstances surrounding the incident or problem.

Waterway shall not be responsible for cartage, removal and/or reinstallation labor, or any other such costs incurred in obtaining warranty replacements. Warranty applies to OEM's and Distributors of Waterway Products.

This warranty gives you specific legal rights. You may also have other rights which very from state to state.





2200 East Sturgis Road, Oxnard, CA 93030 • Ph. (805) 981-0262 • Fax (805) 981-9403 www.waterwayplastics.com • waterway@waterwayplastics.com

810-0067.0109





DELUXE SYSTEM OWNER'S MANUAL

CLEARWATER II D.E. FILTER SYSTEM OWNER'S MANUAL

Our ClearWater II D.E. Filter System is shipped from Waterway complete with everything you need right in the box. Assemble filter system only after above-ground pool is installed. Fill pool with water. Do not raise water level above pool return line.

The pool equipment should be located between pool skimmer and return line. The filtration system should not be closer than 2 ft. and not further than 5 ft. from the pool. The ClearWater II D.E. Filter System needs to be on a completely flat surface (e.g. patio block, cement slab, etc.). The pump will require a 110 volt/20 amp service.



WARNING: A GFCI is required. Follow national and local building and safety codes.

Before opening shipping carton, make sure box is in the upright position. Inside the carton, you will find:

- 1. One base
- 2. One pump (packaged in separate box)
- 3. One filter
- 4. Two lengths of 6 ft. hose
- 5. One bag with fittings

INSTALLATION INSTRUCTIONS




WARNING! READ ALL INSTRUCTIONS AND WARNING LABELS BEFORE OPERATING FILTER!

- 1. Place filter and base on a level, secure surface. Open fittings bag and remove coupling assembly (Detail 2). Assemble 2" gasket, coupling, coupling o-ring, and 2" union nut, and thread into inlet side of filter.
- 2. Open pump trap lid and remove 2" gasket. Place 2" gasket into union nut. Hand tighten union nut to suction side of pump (Detail 2).
- 3. Place the pump on the base to the left of the filter. The pump should align with coupling on filter side marked "Inlet". There is no need to disassemble filter or pump assemblies.
- 4. Thread 2" union nut to pump discharge (Detail 2). Thread gate valve with gasket to pump trap suction side (Detail 2).
- 5. Secure pump to base using the pin and anchor assemblies (Detail 1).
- 6. From the fittings package, remove 1 ½" hose adapter and o-ring (Detail 2). Thread into outlet side of the filter tank.

- 7. Remove 4 hose clamps from the fittings bag. Select one of the hose lengths and slip one clamp over the end of the hose adapter. Place the end of the hose on to the gate valve (pump suction) and the other end to the hose adapter end of the pool skimmer. Repeat steps with filter outlet to pool return.
- 8. Remove the lid handle, #1, from the fittings bag and attach it to the top of the lid assembly, #12, as shown (Detail 3). Secure ClearWater Filter to ClearWater Filter Base using #26a Phillips-head screws (2), (Detail 4 & 5). Fill pool until water level is halfway up length of skimmer throat.
- 9. Open air release knob. Plug in and turn on pump. Air will pass out of the filter through the air release knob. Once water discharges from knob, close it.

NOTE: To remove lid assembly, take off filter nut, #3, insert filter wrench, #20a, in notch between filter body, #20 and lid assembly, #12, twist and separate as shown in Detail 5.



CLEADWATED II DE EILTED CYCTEM DEDLACEMENT DADTC

17 19-7249 Locator - Top Grids - D.E. 18 550-7210 Grids - 12 sq. ft. D.E. (7) 550-7220 Grids - 18 sq. ft. D.E. (7) 550-7220 Base Assembly - 18 sq. ft. 550-7120 Base Assembly - 18 sq. ft. 519-7470 Filter Body - Bottom Filter Wrench (see Detail 5) 20			CLEARWATER II D.E FILT	ER SYSTEM REPLACEMENT	PARTS
2 819-9002 All X ks SS Phillips Head Screw 718-7251 Filter Lockout Assembly 4 602-2000 All Relief Plug 5 805-0207 O-Ring- Air Relief Plug 5 805-0207 O-Ring- Air Relief Plug 6 830-400055 Pressure Gauge 9 Handle Assembly (2) 8 805-0224 O-Ring- Air Relief 9 519-7451 Handle Assembly (2) 8 805-0224 O-Ring- Air Relief 9 519-7451 Uid Assembly (2) 10 805-01750 D-Ring- Adapter 9 10 805-01750 D-Ring- 8 10 8 10 8 10 8 10 8 10 8 10 8 10 8 1	Item	Part No.	Description ————————————————————————————————————		
3 718-7251 Filter Lockmut Assembly 4 602-0200 Air Relief Plug 5 805-0207 O-Ring- Air Relief 7 159-7451 Handle Assembly (2) 8 805-0224 O-Ring- Air Relief 9 519-7430 Gauge - Fitting Adapter 12 12 12 12 13 14 14 15 15 14 14 15 15	1	519-7601	Lid Handle	2	3
4 602-0200 Air Relief Plug 6 830-40005 Pressure Gauge 7 519-7451 805-0224 O-Ring - Air Relief 8 805-0220 O-Ring - Air Relief 8 805-0220 O-Ring - Air Relief 9 519-7451 805-024 O-Ring - Air Relief 10 805-01175 D-Ring - Adapter 11 805-0460 Lid O-Ring - Air Relief 12 519-7411 Lid Assembly (small) 519-7411 Lid Assembly (small) 519-7410 Lid Assembly (large) 13 519-7441 Viling-Nut 14 500-7310 Scenestosk Assembly 15 718-7210 Die Rut - D.E. 16 419-7221 Plug - 2'x 1-1/w MPT Lid Cator - Top Grids - D.E. 17 519-7269 Crids - 12-9, th. D.E. (7) 18 50-7210 Base Assembly - 18-9, ft. 18 550-7210 Base Assembly - 18-9, ft. 19 550-7100 Base Assembly - 18-9, ft. 19 55	2	819-9002	#12 x ¾" S/S Phillips Head Screw		
5 805-0207 O-Ring-Air Relief 6 830-4000S5 Pressure Gauge 7 519-7451 Handle Assembly (2) 8 805-0224 O-Ring-Air Relief 9 519-7430 Gauge-Riting Adapter 10 805-011750 O-Ring-Air Relief 11 805-0460 Lid-Assembly (large) 11 805-0460 Lid-Assembly (large) 11 805-0460 Lid-Assembly (large) 11 805-0460 Lid-Assembly (large) 11 519-7411 Lid-Assembly (large) 11 519-7411 Lid-Assembly (large) 11 519-7411 Ving-Nut 14 500-7310 Screen/Sock Assembly 15 718-7210 Tie-Nut-D.E. 16 419-7241 Plug-2"x 1 ½" MPT 17 519-7269 Locator-Top-Grids-D.E. 18 550-7220 Grids-18-94, FLDE. (7) 18 550-7220 Base Assembly-1 8 sq. ft. 18 550-7210 Base Assembly-1 8 sq. ft. 19 550-7100 Base Assembly-1 8 sq. ft. 19 550-7100 Base Assembly-1 8 sq. ft. 19 550-7100 Base Assembly-1 8 sq. ft. 19 550-7220 Crids-1 8 sq. ft. 10 550-7220 Crids-1 8 sq. ft. 10 550-7220 Crids-1 8 sq. ft. 10 550-7220 Crids-1 8 sq. ft. 11 10 10 10 10 10 10 10 10 10 10 10 10 1	3	718-7251	Filter Locknut Assembly	1	
6 830-40005S Pressure Gauge 7 519-7451 Handle Assembly (2) 8 805-0224 O-Rimp - Air Relief 9 519-7450 Gauge - Ritting Adapter 10 805-01750 O-Rimp - Air Relief 11 805-0460 Lid O-Rimg 12 519-7411 Lid Assembly (small) 519-7401 Lid Assembly (small) 519-7401 Lid Assembly (small) 13 519-7401 Lid Assembly (small) 14 500-7310 ScreenSock Assembly 15 718-7210 Tie Nut - D.E. 16 419-7241 Plug - 2"x 1" MPT 17 519-7269 Locator - Top Grids - D.E. 18 550-7210 Grids - 12-9, ft D.E. (7) 19 550-7120 Base Assembly - 12 sq. ft. 550-7120 Base Assembly - 18 sq. ft. 550-7120 Base Assembly - 18 sq. ft. 550-7120 Base Assembly - 18 sq. ft. 550-7120 Grids - 12-9, ft D.E. (7) 19 550-7120 Condition - Standard - Sta	4	602-0200	Air Relief Plug		
S90-4005 Pressure Gauge Pressure G	5	805-0207	O-Ring - Air Relief		89
8 805-0224 O-Ring - Are Relief 9 519-7430 Gauye - Fitting Adapter 10 805-011750 O-Ring - Adapter 11 805-0460 Lid O-Ring 12 519-7411 Lid Assembly (snall) 519-7401 Lid Assembly (snall) 519-7401 Lid Assembly (snall) 519-7401 Tie Nut - D.E. 16 419-7241 Plug - 2" x 1 12" MPT 17 519-7269 Locator - Top Grids - D.E. 18 550-7210 Grids - 12-5g. t. D.E. (7) 19 550-7100 Base Assembly - 13-5g. t. D.E. (7) 19 550-7100 Base Assembly - 13-5g. t. D.E. (7) 19 550-7100 Base Assembly - 18-5g. t. D.E. (7) 19 550-720 Grids - 12-5g. t. D.E. (7) 19 672-7401 ClearWard Hose Back 26a 879-040 Filter Wench (5ee Detail 5) 21 805-0330 Drain Assembly 26a 879-040 Grids - 12-5g. d. D.E. d. D.E	6	830-4000SS	Pressure Gauge		
8 805-0224 O-Ring - Alt Reier 12 12 13 14 15 15 15 16 16 17 16 17 16 17 16 17 16 17 16 17 17	7	519-7451	· · · · · · · · · · · · · · · · · · ·		20a 🖢 💮
10 805-01175D O-Ring - Adapter Lid O-Ring 12 519-7411 Lid Assembly (Small) 519-7411 Lid Assembly (Small) 519-7411 Lid Assembly (Barge) 13 519-7411 Lid Assembly (Barge) 14 500-7310 Screen/Sock Assembly 15 718-7210 Lid Assembly (Barge) 15 718-7210 Lid Assembly 17 18 72141 Pluy 2-7x 1 1y* MPT 17 519-7269 Locator - Top Grids - D.E. (7) 550-7120 Grids - 12 sq. ft. D.E. (7) 550-7120 Base Assembly - 12 sq. ft. D.E. (7) 550-7120 Base Assembly - 12 sq. ft. D.E. (7) 550-7120 Base Assembly - 12 sq. ft. D.E. (7) 550-7120 Base Assembly - 12 sq. ft. D.E. (7) 67-7470 Grids - 18 sq. ft. DE. (7) 67-7410 Grids - 18 sq. ft. DE. (7) 7-7410 Grids -	8		<u> </u>		
11 805-0460 Lid 0-Ring 1 Lid Assembly (small) 1519-7411 Lid Assembly (large) 1 20 20 20 20 20 20 20 20 20 20 20 20 20					
11 505-0460				{}	26a
519-7401 13 519-7441 14 500-7310 578-7210 15 Nut - D.E. 16 419-7241 1 Plug - 2" x 1 ½" MPT 15 19-7269 16 Grids - 12 sq. ft. D.E. (7) 17 519-7269 18 550-7210 18 550-7210 19 550-7100 19 8ase Assembly - 18 sq. ft. 19 550-7100 19 8ase Assembly - 18 sq. ft. 10 515-7251 1 Riter Body - Bottom 11 12 Windle Wench (see Detail 5) 20 515-7251 21 805-0224 22 417-6241 23 872-9002 24 117-6241 25 500-5300 26 117-7401 27 Union Nut 26 819-0044 27 415-5001 28 419-7241 29 711-4010 28 419-7241 29 711-4010 29 Union Gasket (2) 27 71-4010 29 11/2 HP - 1-Speed - Supreme Pump 29 711-4010 29 11/2 HP - 1-Speed - Supreme Pump 29 FSP2100 21 1/2 HP - 1-Speed - Supreme Pump 29 FSP2100 21 1/2 HP - 2-Speed - Supreme Pump 24 31 11520 33 805-0330 31 11520 33 805-0330 31 11520 33 805-0330 31 11520 33 805-0330 31 11520 33 805-0330 31 11520 33 805-0330 31 11520 33 805-0330 31 11520 33 805-0330 31 PSP1150 31 PSP1150 31 PSP1500 31 PSP1500 31 PSP1500 31 PSP2100 31 PSP2200 31 PSP2300 31 PSP1500 3			-		
Sip-7441 Wing-Nut	12		· · · · · · · · · · · · · · · · · · ·		20
14 500-7310 Screen/Sock Assembly T18-7210 T18 Nut - Dic. 15 718-7210 T18 Nut - Dic. 16 419-7241 Pluy-2" x 1 ½" MPT 17 519-7269 Locator - Top Grids - D.E. 18 550-7210 Grids - 12 sq. ft. DE. (7) 19 550-7100 Base Assembly - 12 sq. ft. 550-7210 Grids - 18 sq. ft. DE. (7) 19 550-7100 Base Assembly - 12 sq. ft. 550-7100 Base Assembly - 12 sq. ft. 550-7120 Base Assembly - 12 sq. ft. 550-7120 Base Assembly - 18 sq. ft. 19 550-7120 Base Assembly - 12 sq. ft. 550-72521 Filter Body - Bottom 519-7470 Filter Wrench (see Detail 5) 21 805-0224 O-Ring (3) 22 417-6241 1½" MPT x 1½" Male Smooth Hose Adapter 43 872-9002 Corrugated Hose - Black 500-5300 Drain Assembly 25 500-5300 Drain Assembly 26 672-7401 ClearWater II Base 26 672-7401 ClearWater II Base 26 672-7401 ClearWater II Base 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 31 PSP1100 THP 1-Speed - Supreme Pump PSP1100 THP 1-Speed - Supreme Pump PSP2100 THP 2-Speed - Supreme Pump PSP2100 The 1-Speed - Supreme Pump 20 28 27 21 22 24 22 24 25 23 25 27 24 25 26 25 26 27 26 27 27 27 28 27 28 27 29 28 27 20 28 27 21 22 24 22 23 24 23 24 24 25 25 25 26 27 26 27 27 28 28 28 27 29 28 27 20 28 27 21 22 22 23 23 24 24 25 25 25 26 27 26 27 27 28 28 28 27 29 28 27 20 28 27 21 22 22 23 23 24 24 24 24 25 26 26 27 26 28 27 28 28 27 29 28 27 20 28 2					
15			-		
16			•		
17 519-7269 10 17 17 17 17 17 18 10 10 10 10 10 10 10					26a
S50-7210			_		
550-7200 Grids - 18 sq. ft. D.E. (7) 550-7100 Base Assembly - 12 sq. ft. 550-7120 Base Assembly - 12 sq. ft. 550-7120 Base Assembly - 18 sq. ft. 750-7125 Filter Body - Sottom Filter Wrench (see Detail 5) 76-7126 Base Assembly - 18 sq. ft. 77-7127 Filter Body - Sottom Filter Wrench (see Detail 5) 78-7127 Filter Wrench (see Detail 5) 78-7128 Filter Wrench (see Detail 5) 78-7129 Fi			•	DETAIL 3	DETAIL 4
S50-7100	18		•		
550-7120 Base Assembly - 18 sq. ft. Filter Body - Bottom 20a 515-7251 Filter Body - Bottom 21 805-0224 O-Ring (3) 22 417-6241 1½" MPI x 1½" Male Smooth Hose Adapter 23 872-0010 Hose Clamp - Stainless Steel 24 872-9002 Corrugated Hose - Black 25 500-5300 Drain Assembly 26 672-7401 Clear/Water II Base 26a 819-0044 #10 x 1" S/S Phillips Head Screw (2) 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1200 2HP - 1-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2100 1½ HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme P	10		•		
20a 515-7251 Filter Body - Bottom 20a 519-7470 Filter Wrench (see Detail 5) 21 805-0224 O-Ring (3) 22 417-6241 1½" MPT x ½" Male Smooth Hose Adapter 23 872-0010 Hose Clamp - Stainless Steel 24 872-9002 Corrugated Hose - Black 25 500-5300 Drain Assembly 26 672-7401 (ClearWater II Base 26a 819-0044 #10 x 1" 5/5 Phillips Head Screw (2) 27 415-5001 2" Union Nut 28 419-7221 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1200 2HP - 1-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2100 311-1520 Faceplate - Supreme Pump PSP2200 2HP - Speed - Supreme Pump PSP2100 311-1520 Faceplate - Supreme Pump PSP2300 311-1520 Faceplate - Supreme Pump PSP2300 311-1530 Supreme Pump TSP2300 311-1530 Supreme Pump TSP2400 Supreme Pump TSP2500 310-1530 Supreme	19				1 2
20a 519-7470 Filter Wrench (see Detail 5) 21 805-0224 O-Ring (3) 22 417-6241 1½" MPT x 1½" Male Smooth Hose Adapter 3872-0010 Hose Clamp - Stainless Steel 24 872-9002 Corrugated Hose - Black 25 500-5300 Drain Assembly 26 672-7401 ClearWater II Base 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1200 2HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP200 2HP - 2-Speed - Supreme Pump PSP200 2HP - 2-Speed - Supreme Pump PSP200 2HP - 2-Speed - Supreme Pump PSP33 805-0330 O-Ring 32 311-1520 Faceplate - Supreme Pump 33 805-0330 O-Ring 34 319-1510 Supreme Pump Trap Body 35 319-1540 C-Clip - Supreme Pump 36 319-1530 Supreme Trap Basket 37 805-0439 O-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve	20				
21 805-0224			•		6
22 417-6241 1½" MPT x 1½" MPT x 1½" Male Smooth Hose Adapter 23 872-0010 Hose Clamp - Stainless Steel 24 872-9002 Corrugated Hose - Black 25 500-5300 Drain Assembly 26 672-7401 Clear/Mater II Base 26a 819-0044 #10 x 1" S/S Phillips Head Screw (2) 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1200 2HP - 1-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 1½ HP - 1-Speed - Supreme Pump PSP2100 1½ HP - 1-Spee					7 9 9 7 7
## Representation of Process of Parameters			=		8 9 10
24 872-9002 Corrugated Hose - Black 25 500-5300 Drain Assembly 26 672-7401 ClearWater II Base 26a 819-0044 #10 x 1" S/S Phillips Head Screw (2) 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1100 1HP - 1-Speed - Supreme Pump PSP2100 2HP - 1-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2100 C-Clip - Supreme Pump 32 311-1520 Faceplate - Supreme Pump 33 805-0330 O-Ring 34 319-1540 C-Clip - Supreme Pump 35 319-1540 Supreme Pump Trap Body 36 319-1530 Supreme Trap Basket 37 805-0439 O-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve			•		
25 500-5300 Drain Assembly 26 672-7401 ClearWater II Base 26a 819-0044 #10 x 1" 5/5 Phillips Head Screw (2) 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1150 1½ HP - 1-Speed - Supreme Pump PSP2100 2HP - 1-Speed - Supreme Pump PSP2100 1½ HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2100 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP200 2HP - 2-Speed - Supreme Pump PSP2100 C-Clip - Supreme Pump Supreme Pump Trap Body 20 0-Ring 319-1510 Supreme Pump Trap Body 21 22 24 33 319-1510 Supreme Pump 34 319-1510 Supreme Pump 35 319-1530 Supreme Trap Basket 36 319-1530 Supreme Trap Basket 37 805-0439 O-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve				26a	
26 672-7401 ClearWater II Base 26a 819-0044 #10 x 1" S/S Phillips Head Screw (2) 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1200 2HP - 1-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2150 1½ HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2150 1½ Supreme Pump PSP2150 1½ Supreme Pump PSP2150 1½ Supreme Pump PSP2150 1½ Supreme Pump PSP2150 244 36 36 36 36 36 36 36 36 36 36 36 36 36			-		< 12
26a 819-0044 #10 x 1" 5/5 Phillips Head Screw (2) 27 415-5001 2" Union Nut 28 419-7241 Coupling 29 711-4010 2" Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1200 2HP - 1-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2100 1HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP2200 2HP - 2-Speed - Supreme Pump PSP233 805-0330 0-Ring 34 319-1510 Supreme Pump Trap Body 35 319-1540 (-Clip - Supreme Pump 36 319-1530 Supreme Trap Basket 37 805-0439 0-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve			•	DETAIL 5	
27 415-5001 2"Union Nut 28 419-7241 Coupling 29 711-4010 2"Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1HP - 1-Speed - Supreme Pump PSP1150 1½ HP - 1-Speed - Supreme Pump PSP2100 2 HP - 1-Speed - Supreme Pump PSP2150 1½ HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP233 805-0330 0-Ring 34 319-1510 Supreme Pump Trap Body 35 319-1540 C-Clip - Supreme Pump 36 319-1530 Supreme Trap Basket 37 805-0439 0-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve	26a	819-0044	#10 x 1" S/S Phillips Head Screw (2)	DETAIL	13
28	27	415-5001	2" Union Nut		ń
29 711-4010 2"Union Gasket (2) 30 429-7221 Snap Pin (4) 31 PSP1100 1 HP - 1-Speed - Supreme Pump PSP1150 1½ HP - 1-Speed - Supreme Pump PSP1200 2 HP - 1-Speed - Supreme Pump PSP2150 1½ HP - 2-Speed - Supreme Pump PSP2150 1½ HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP2150 Faceplate - Supreme Pump 33 805-0330 O-Ring 34 319-1510 Supreme Pump Trap Body 25 21 22 24 36 319-1530 Supreme Pump Trap Body 26 319-1530 Supreme Trap Basket 37 805-0439 O-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve	28	419-7241	Coupling		
30			2" Union Gasket (2)		
PSP1150			•	38	
PSP1200 2 HP - 1-Speed - Supreme Pump PSP2100 1 HP - 2-Speed - Supreme Pump PSP2150 1½ HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump PSP2200 2 HP - 2-Speed - Supreme Pump 32 311-1520 Faceplate - Supreme Pump 33 805-0330 0-Ring 34 319-1510 Supreme Pump Trap Body 35 319-1540 C-Clip - Supreme Pump 36 319-1530 Supreme Trap Basket 37 805-0439 0-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve	31				10
PSP2100			· · · · · · · · · · · · · · · · · · ·	37	
PSP2150 PSP2150 PSP2200 PSP220			2.4		↓ ← 19
PSP2150			i ili - 2-speed - supreme i dilip	36	20
32					
32 311-1320 Faceplate - Supreme Pump 33 805-0330 O-Ring 34 319-1510 Supreme Pump Trap Body 35 319-1540 C-Clip - Supreme Pump 36 319-1530 Supreme Trap Basket 37 805-0439 O-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve	22		Z III - Z-Speed - Supremer unip		
34 319-1510 Supreme Pump Trap Body 35 319-1540 C-Clip - Supreme Pump 36 319-1530 Supreme Trap Basket 37 805-0439 O-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve			Faceplate - Supreme Pump	0	21 22 24
34			Common Doman Trans Darks) \ 77 / / /
36					
37 805-0439 O-Ring 38 511-1310 Trap Lid 39 WV001H Gate Valve			· · · · · · · · · · · · · · · · · · ·		
38 511-1310 Trap Lid 39 WV001H Gate Valve			·	33	30 31
39 WV001H Gate Valve 30 31 26a (2)				32	25 23
26a (2)					
	JZ	44 A OO I IJ	Jate valve	۰ اد	
					26a (2)