CLEANING INSTRUCTIONS

If the pressure gauge on your filter reads 5 PSI or higher than the original starting pressure, the filter needs to be cleaned. The ClearWater II D.E. Filter System features the exclusive 1-2-3 Safety Locking System to ensure safe and simple filter maintenance.

- 1. Turn off pump. WARNING: Never attempt to clean filter while pump is running. This is a pressurized vessel. It could cause severe injury or harm to your person. Plug skimmer and pool return lines or drain pool water level to below pool return line.
- Slowly open the air release knob on top of filter until the pressure gauge reads "0". Open drain cap at bottom of filter and allow water to flow.

- 3. Press the yellow safety latch on the underside of the locking nut and turn the nut counterclockwise to remove the lid. Rinse the D.E. element with a garden hose. There is no need to remove the element from the filter.
- 4. Reassemble lid and follow start-up procedures from original instructions.

Ny Original Starting Pressure is	_ PSI (Pounds per
guare Inch). I should clean the filter at	PSI.

LIMITED WARRANTY

Waterway Plastics manufactures its products and equipment in accordance with very high standards of workmanship. We use the best materials available and maintain the highest quality procedures practical in the industry. In accordance, Waterway warrantys its products as follows:

All plastics parts such as jets, valves, skimmers, manifolds, suctions, lights, and other plastic components manufactured by Waterway will be replaced or repaired, if the defects are determined by Waterway to be the responsibility of Waterway Plastics, for a period of three years from the date of installation. The warranty does not cover filter cartridges, D.E. grids, O-rings, pressure gauges, pump seals, light bulbs or any parts not manufactured by Waterway. Warranty applies to OEM's and Distributors of Waterway Products.

The Supreme and Hi-Flo Pumps will receive limited warranty from any defect in material or workmanship for one year from the date of manufacture. This includes the motor but not the motor seal.

All thermoplastic molded filter bodies and rotational molded sand filter bodies have a warranty of ten years, warranted on a pro-rata life basis. If a defect becomes apparent during the first year, the body will be exchanged for a new body if the defects are determined by Waterway to be the responsibility of Waterway Plastics. If a defect becomes apparent after the first year from the date of manufacture which, in the opinion of Waterway, will require

replacement, the body will be exchanged for a new tank on an adjusted service pro-rata life basis. Charges to the owner, on the pro-rata life basis, will be determined by the actual number of months installed beginning with the date of installation.

Products that fail or become defective during the warranty period, except as a result of improper installation, bad water chemistry, accidents or negligence on behalf of the owner, freezing, earthquakes, fire floods, or other acts of nature, shall be repaired or replaced at Waterway's option without charge to the owner. This process will be completed within 90 days of receipt of the defective product barring delays caused by the acquisition of component parts not manufactured at our facility.

To obtain warranty replacements or repair, defective products should be returned (transportation paid) to the place of purchase, or to Waterway. It should include a description of the defect and the circumstances surrounding the incident or problem.

Waterway shall not be responsible for cartage, removal and/or reinstallation labor, or any other such costs incurred in obtaining warranty replacements. Warranty applies to OEM's and Distributors of Waterway Products.

This warranty gives you specific legal rights. You may also have other rights which very from state to state.





2200 East Sturgis Road, Oxnard, CA 93030 • Ph. (805) 981-0262 • Fax (805) 981-9403 www.waterwayplastics.com • waterway@waterwayplastics.com

810-0079.1008







CLEARWATER II D.E. FILTER SYSTEM OWNER'S MANUAL

Our ClearWater II D.E. Filter System is shipped from Waterway complete with everything you need right in the box. Assemble filter system only after above-ground pool is installed. Fill pool with water. Do not raise water level above pool return line.

The pool equipment should be located between pool skimmer and return line. The filtration system should not be closer than 2 ft. and not further than 5 ft. from the pool. The ClearWater II D.E. Filter System needs to be on a completely flat surface (e.g. patio block, cement slab, etc.). The pump will require a 110 volt/20 amp service.



WARNING: A GFCI is required. Follow national and local building and safety codes.

Before opening shipping carton, make sure box is in the upright position. Inside the carton, you will find:

- 1. One base
- 2. One pump (packaged in separate box)
- 3. One filter
- 4. Two lengths of 6 ft. hose
- 5. One bag with fittings

INSTALLATION INSTRUCTIONS




WARNING! READ ALL INSTRUCTIONS AND WARNING LABELS BEFORE OPERATING FILTER!

- 1. Place filter and base on a level, secure surface. Place the pump on the base to the left of the filter. The pump should now be facing the filter marked "Inlet". There is no need to disassemble filter or pump assemblies.
- 2. Open pump trap lid and remove 2" gasket. Place 2" gasket into union nut. Hand tighten union nut to suction side of pump (Detail 5).
- 3. Secure pump to the base using the pin & anchor assemblies (Detail 4).
- 4. Open fittings bag and remove coupling assembly (Detail 2). Assemble 2" gasket, coupling, coupling O-Ring, and 2" union nut, and thread into inlet side of filter.
- 5. Thread 2" union nut to pump discharge (Detail 3). Thread hose adapter with O-Ring, to pump trap suction side (Detail 1).
- 6. From the fittings package, remove 1½" hose adapter and 0-ring

(Detail 2, #21 & 22). Thread into the outlet side of the filter tank.

- 7. Remove 4 hose clamps from the fittings bag. Select one of the hose lengths and slip one clamp over the end of hose adapter. Place the end of the hose on to the hose adapter (pump suction) and the other end to the hose adapter end of the pool skimmer. Repeat steps with filter outlet to pool return.
- Remove the Lid Handle, #1, from the fittings bag and attach it to the top of the Lid Assembly, #12, as shown (Detail 6). Secure ClearWater Filter to ClearWater Filter Base using #24a Phillips Head Screws (2) (Detail 6a & 6aa). Fill pool until water level is halfway up length of skimmer throat.
- 9. Open air release knob. Plug in and turn on pump. Air will pass out of the filter through the air release knob. Once water discharges from knob, close it.

NOTE: To remove Lid Assembly, take off Filter Nut, #3, insert Filter Wrench, #20a, in notch between Filter Body, #20 and Lid Assembly, #12, twist and separate as shown in Detail 6a.



CLEADWATED II D.E. EILTED CVCTEM DEDI ACEMENT DADTO

26 419-7241 Coupling 24a 15 —			CLEARWATER II D.I	E. FILTER SYSTEM REPLACEMENT I	PARTS			
2 319-902 Air Schellings lead Screw (2) 21 32 30 30 310-32 (3) 412 x lr Schellings lead Screw (2) 21 31 30 310-32 (3) 415 x lr Schelling lead Screw (2) 21 31 30 310-32 (3) 415 x lr Schelling lead Screw (2) 21 31 30 310-32 (3) 415 x lr Schelling lead Screw (2) 21 31 30 310-32 (3) 415 x lr Schelling lead Screw (2) 21 31 30 310-32 (3) 415 x lr Schelling lead Screw (2) 21 31 310 310 310 310 310 310 310 310 310	Item	Part No.	Description		1			
2 819-902	1	519-7601	Lid Handle	22 33	2			
10	2	819-9002	#12 x ¾" S/S Phillips Head Screw		A.			
5 805-0207 O-Ring-Air Relief 6 830-00005 Psysue Gauge 7 519-7451 do-Ring-Air Relief 9 519-7451 Gauge-Fitting Adapter 10 805-0640 Lid-Ning-Air Relief 11 805-0640 Lid-Ning-Air Relief 12 519-7411 Lid Assembly (Small) 1519-7411 Lid Assembly (Small) 1519-7411 Lid Assembly (Small) 1519-7411 Lid-Assembly (Rmall) 15 519-7411 Lid-Assembly (Rmall) 15 519-7411 Lid-Assembly (Rmall) 16 419-7241 Ping-2"x 1" N" MPT 17 519-7269 Lector's rop Grids - D.E. 16 419-7210 D.E. Grids - 12s, ft. (7) 18 550-7210 D.E. Grids - 12s, ft. (7) 19 550-7100 Base Assembly - 12s, ft. 150-720 D.E. Grids - 12s, ft. (7) 20 519-7270 D.E. Grids - 18s, ft. (7) 20 519-7270 D.E. Grids - 18s, ft. (7) 20 519-7270 Base Assembly - 12s, ft. 20 11-7470 Filter Wench (see Detail Ga) 20 Filter Air St. (7) 21 805-0224 O-Ring (4) 22 417-6241 O-Ring (4) 23 500-5300 Deain Assembly 24 672-7401 ClaryMare II Base Howen (1) 25 415-5001 2" Union Nut Coupling 27 711-4010 2" Union Saket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1HP - 1-Speed Hi-Rio Pump PH1200 1HP - 1-Speed Hi-Rio Pump PH1200 2HP - 1-Speed Hi-Rio Pump PH1200 1HP - 2-Speed Hi-Rio Pump PH1201 1HP - 2-Speed Hi-Rio Pump PH1201 1HP - 2-Speed Hi-Rio Pump PH1202 1HP - 2-Speed Hi-Rio Pump PH1203 1HP - 2-Speed Hi-Rio Pump PH1204 1HP - 2-Speed Hi-Rio Pump PH1205 1HP - 2-Speed Hi-Rio Pump PH1206 1HP - 2-Speed Hi-Rio Pump PH1207 1HP - 2-Speed Hi-Rio Pump PH1208 1HP - 2-Speed Hi-Rio Pump PH1209 1HP - 2-Speed Hi-Rio Pump PH1200 1HP - 2-Speed	3	718-7251	•	32				
6 830-4000SS Pressure Gauge 8 7 519-7451 Handle Assembly (2) 8 805-0224 O-king- Air Relief 9 519-7430 Gauge- Fitting Adapter 10 805-0460 Lid O-Ring 11 805-0460 Lid O-Ring 13 519-7411 Lid Assembly (Small) 519-7401 Sip-7441 Wind Seembly (Small) 14 500-7310 Screen/Sock Assembly 15 718-7210 DE Ginds - 12s. g. ft. (7) 15 19-7229 De Contor - Top Ginds - 12s. g. ft. (7) 17 519-7220 DE Ginds - 12s. g. ft. (7) 19 550-7220 DE Ginds - 12s. g. ft. (7) 19 550-7120 Base Assembly - 18 sq. ft. (7) 19 550-7120 Base Assembly - 18 sq. ft. (7) 19 550-7120 Base Assembly - 18 sq. ft. (7) 19 550-7120 Base Assembly - 18 sq. ft. (7) 20 515-7251 Base Assembly - 18 sq. ft. (7) 21 805-0224 O-king (4) 22 417-6241 11s' km/rx 1 b'' Male Smooth Hose Adapter (2) 23 500-5300 Drain Assembly 24 672-7401 Cland/kater Il Base 410 x 1'S 55 Phillips Head Screw (2) 24 819-0044 # 10 x 1'S 55 Phillips Head Screw (2) 25 415-5001 2' Union Nut 26 419-7241 Coupling PH1250 1b H- 1-Speed Hi-Fio Pump PH1250 1b H- 2-Speed Hi-F	•		-		1 1			
7	_		-	21 27				
8 805-0224 O-Ring -Air Relef 30 9 519-7430 Gauge - Ritting Adapter 10 805-011750 O-Ring - Adapter 11 805-0460 Lid O-Ring 519-7401 Lid Assembly (Small) 519-7401 Lid Assembly (Small) 519-7401 Wing-Nut 500-7310 Socreen/Sock Assembly 15 718-7210 IP Nut - D.E. 16 419-7241 Plug - 2" x 1 1/2" MPT 17 519-7269 D.E. Ginds - 12 sq. ft. (7) 550-7120 D.E. Ginds - 12 sq. ft. (7) 550-7120 Base Assembly - 12 sq. ft. (8) 550-7120 D.E. Ginds - 12 sq. ft. (7) 550-7120 Base Assembly - 18 sq. ft. (7) 550-7120 Base Assembly - 18 sq. ft. (7) 550-7120 The Ring of the Proper 18 sq. ft. (7) 550-7120 The Ring of the Proper 19 550-7120 The Ring of the Proper 11 805-0224 O-Ring (4) O-Ring (4) 22 417-6241 13" MPT x 1" Male Smooth Hose Adapter (2) 23 500-5300 Drain Assembly 24 672-7401 Clasr/Mater II Base 419-7241 Clasr/Mater II Base 419-7241 Clasr/Mater II Base 419-7241 Clasr/Mater II Base 419-7241 Tri-4010 2" Union Nat Clasr/Mater II Base 419-7241 Tri-4010 2" Union Risket (2) 7 771-4010 2" Union P 19 PH1150 1 19 HP - 1-Speed Hi-Rio Pump PH1200 1 19 HP - 2-Speed Hi-Rio Pump 19 PH1200 2 19 HP - 2-Speed Hi-Rio Pump 19 PH1200 2 19 HP - 2-Speed Hi-Rio Pump 19 PH1200 1 19 HP - 2-Speed Hi-Rio Pump 19 PH1200 1 28 28 29 21 22 23 24 25 26 27 26 27 26 27 26 27 26 27 26 27 26 27 28 29 29 20				31				
9 519-7430 10 805-01175D 11 805-0460 Lid O-Ring - Adapter 12 519-7411 Lid Assembly (maill) 13 519-7401 Lid Assembly (maill) 14 500-7310 15 718-7210 Lid Assembly (maill) 15 718-7210 Lid Assembly - Till A	•							
10 805-011750 O-Ring - Adapter Lid O-Ring 805-0460 Lid O-Ring 12 519-7411 Lid Assembly (Small) Lid Assembly (Large) Lid Assembly Lid Assembly Lid Assembly 15 19-7441 Lid Assembly Lid Assembly Lid Assembly 15 718-7210 Lid Assembly 15 718-7210 Tie Nut - D.E. 16 419-7241 Pluy - 2" x 1 ½" MPT 17 519-7269 Locator - Top folds - D.E. 18 550-7210 D.E. Grids - 18 sp. ft. (7) 550-7220 D.E. Grids - 18 sp. ft. (7) 550-7220 D.E. Grids - 18 sp. ft. (7) 550-7220 Base Assembly - 18 sp. ft. (7) 550-7220 Base Assembly - 18 sp. ft. (7) 550-7220 Base Assembly - 18 sp. ft. (7) 550-7220 D.E. Grids - 18 sp. ft. (7) 550			•	30				
11 805-0460 Lid O-Ring 29 11d Assembly (Small) 519-7411 Lid Assembly (Large) DETAIL 5 12 519-7411 Lid Assembly (Large) DETAIL 5 13 519-7441 Wing-Rut Wing-Rut Wing-Rut Wing-Rut Wing-Rut Signary 15 718-7210 Tie Nut - DE Cardor - Top Grids - DE. 16 419-7241 Plug - 2" x 1 19" MPT 519-7269 Locator - Top Grids - DE. 18 550-7210 DE. Grids - 12 sq. ft. (7) 19 550-7210 Ease Assembly - 13 sq. ft. (7) 19 550-7100 Base Assembly - 13 sq. ft. (7) 19 550-7100 Base Assembly - 18 sq. ft. (7) 19 550-7100 Base Assembly - 18 sq. ft. (7) 19 550-7100 Cardor - Top Grids - DE. 19 Sp. ft. (7) 19 550-7100 Cardor - Top Grids - DE. 19 Sp. ft. (7) 19 550-7100 Cardor - Top Grids - DE. 19 Sp. ft. (7) 20 515-7251 Filtre Body Bottom Hitler Wrench (see Detail Ga) Order - Top Grids - DE. 19 Sp. ft. (7) 21 805-0224 O-Ring (4) 22 417-6241 1½" MPT x 1½" Male Smooth Hose Adapter (2) 23 500-5300 Drain Assembly (ClearWater II Base 47) 24 672-7401 ClearWater II Base 47 24 819-0044 #10 x 1" 55 Penillips Head Screw (2) 25 415-5001 2" Union Nut Coupling 13 Top Top Top PH1100 1P - 1-Speed Hi-Flo Pump PH1150 1½ HP - 1-Speed Hi-Flo Pump PH1200 2 HP - 1-Speed Hi-Flo Pump PH200 1P - 2-Speed Hi-Flo Pump PH200 1P - 2-Speed Hi-Flo Pump PH2100 1½ HP - 2-Speed Hi-Flo Pump PH2100 1P - 2-Speed Hi-Flo Pump PH2200 2 HP - 2-Speed Hi-Flo Pump PH200 3 310-6500 6" Tap - 11½" Buttress x? Hange 6" Basket Assembly 0-24 24 24 24 24 25 25 25 25 25 25 25 25 25 25 25 25 25	-							
S19-7411				29				
519-7401 Wing-Nut 14 500-7310 Screem/Sock Assembly 15 718-7210 Ille Nut - D.E. 16 419-7241 Plug-2" x 1½" MPT 17 519-7269 Locator - Top Grids - D.E. 18 550-7210 D.E. Grids - 12 sq. ft. (7) 550-7120 Base Assembly - 12 sq. ft. 20 515-7251 Filter Body Bottom 21 805-0224 O-Ring (4) 21 805-0224 O-Ring (4) 22 417-6241 1½" MPT x 1½" Male Smooth Hose Adapter (2) 23 500-5300 Drain Assembly 24 672-7401 Clear/Water III Base 24 672-7401 2" Union Nut 25 415-5001 2" Union Saket (2) 26 419-7241 Coupling 27 711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1HP - 1-Speed Hi-Flo Pump PH1200 2HP - 1-Speed Hi-Flo Pump PH1200 2HP - 1-Speed Hi-Flo Pump PH2100 1HP - 2-Speed Hi-Flo Pump PH2100 1HP - 2-Speed Hi-Flo Pump PH2100 1HP - 2-Speed Hi-Flo Pump PH2100 31 13 19-3230 6" Basket Assembly 0" Child Rasket Assembly 0" Ch								
15		519-7401	•	DETAIL 5	DETAIL 6			
15 718-7210	13	519-7441	Wing-Nut					
16			•					
17				3				
18			•		1			
S50-7220 D.E. Grids - 18 sq. ft. (7)			•		1			
S50-7100	18							
550-7120 Base Assembly - 18 sq. ft. Filter Body Bottom Filter Wrench (see Detail 6a) 20a 519-7470 Filter Wrench (see Detail 6a) 21 805-0224 O-Ring (4) 1½" MPT x1 ½" Male Smooth Hose Adapter (2) 22 417-6241 1½" MPT x1 ½" Male Smooth Hose Adapter (2) 24 672-7401 ClearWater II Base 24a 819-0044 #10x 1" 5/5 Phillips Head Screw (2) 25 415-5001 2" Union Saket (2) 5nap Pin (4) 2" Union Saket (2) 5nap Pin (4) 1½" HP 1-5peed Hi-Flo Pump PH1200 2 HP 1-5peed Hi-Flo Pump PH2100 1½ HP 2-5peed Hi-Flo Pump PH2100 1½ HP 2-5peed Hi-Flo Pump PH2200 2 HP 2-5peed Hi-Flo Pump PH2200 2 HP 2-5peed Hi-Flo Pump PH2200 3 HP 2-5peed Hi-Flo Pump PH200 0 6" Tap 1 1½" Buttress x 2" Flange 6" Basket Assembly 0-Ring 33 319-3260 6" Basket Assembly 0-Ring 33 319-3260 6" Tap Lid 24a 24a 24a 25 25 32 27 26 25 32 27 26 25 32 28 29 29 29 29 29 29 29 29 29 29 29 29 29	10		•		-3			
20a 515-7251 Filter Body Bottom 20a 519-7470 Filter Wrench (see Detail 6a) 21 805-0224 O-Ring (4) 22 417-6241 13% MPT x 1 3/5 Male Smooth 4 Hose Adapter (2) 23 500-5300 Drain Assembly 24 672-7401 ClearWater II Base 24 819-0044 #10 x 17 5/5 Phillips Head Screw (2) 25 415-5001 2" Union Nut 26 419-7241 Coupling 27 711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 11½ 11½ -1-Speed Hi-Flo Pump 21½ PH1100 1½ PP -1-Speed Hi-Flo Pump 21½ PH2100 2½ PP -1-Speed Hi-Flo Pump 21½ PH2100 1½ PP -2-Speed Hi-Flo Pump 21½ PH2100 1½ PP -2-Speed Hi-Flo Pump 230 310-6500 6" Tap -1 1½" Buttress x 2" Flange 31 319-3230 6" Basket Assembly 32 805-0436 O-Ring 33 319-3260 6" Tap Lid 28 29 20 21 22 21 22 23 22 21 22 23 22 21 22 23 22 21 22 21 22 21 22 21 22 21 28	17				7 6 9 7 7			
20a 519-7470 Filter Wrench (see Detail 6a) 21 805-0224 O-Ring (4) 22 417-6241 1/5" MPT x 15" Male Smooth Hose Adapter (2) 23 500-5300 Drain Assembly 24 672-7401 ClearWater II Base 24a 819-004 #10 x 1" 5/5 Phillips Head Screw (2) 25 415-5001 2" Union Nut 26 419-7241 Coupling 27 711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1HP -1-Speed Hi-Flo Pump PH1200 2HP -1-Speed Hi-Flo Pump PH200 1HP -2-Speed Hi-Flo Pump PH2100 1HP -2-Speed Hi-Flo Pump PH2100 1HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH230 310-6500 6" Tap -1 1/5" Buttress x 2" Hange 31 319-3230 6" Basket Assembly 32 805-0436 O-Ring 33 319-3260 6" Tap Lid 28 29 20 21 22 21 22 23 22 21 24 24a 24a 24a 25 26 25 26 25 27 26 25 28 29	20			\ 20a 3 = /	8 5			
21 805-0224 O-Ring (4) 22 417-6241 1½" MPT x 1½" Male Smooth Hose Adapter (2) 23 500-5300 Drain Assembly 24 672-7401 Clear/Water II Base 24a 819-0044 #10x 1" S/S Phillips Head Screw (2) 25 415-5001 2" Union Rut 26 419-72241 Coupling 27 711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1HP -1-Speed Hi-Flo Pump PH1200 2HP -1-Speed Hi-Flo Pump PH2100 1HP -2-Speed Hi-Flo Pump PH2100 1HP -2-Speed Hi-Flo Pump PH2100 1HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 310-6500 6" Tap -11%" Buttress x 2" Hange 31 319-3230 6" Basket Assembly 32 805-0436 O-Ring 33 319-3260 6" Tap Lid 28 29 20 21 21 22 21 22 23 22 24 24 24a 24a 24a 24a 24a 24a 24a 24				12	11 9 10			
Hose Adapter (2) Drain Assembly (1ear/Water II Base His 90-044 Hi 10 x 1" 5/5 Phillips Head Screw (2) His 90-044 Hi 10 x 1" 5/5 Phillips Head Screw (2) His 101	21	805-0224	0-Ring (4)					
Hose Adapter (2) Drain Assembly ClearWater II Base 24a 819-0044 #10 x 1" 5/5 Phillips Head Screw (2) 25 415-5001 2" Union Nut 26 419-7241 Coupling 27 7711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) PH1100 1H/P -1-Speed Hi-Flo Pump PH1200 2H/P -1-Speed Hi-Flo Pump PH2100 1H/P -2-Speed Hi-Flo Pump PH2100 1H/P -2-Speed Hi-Flo Pump PH2100 1H/P -2-Speed Hi-Flo Pump PH2200 2H/P -2-Speed Hi-Flo Pump PH2200 2H/P -2-Speed Hi-Flo Pump PH2200 5H/P -2-Speed Hi-Flo Pump PH2200 0-SH/P -2-Speed Hi-Flo Pump PH2300 0-SH/P -2-Speed Hi-Flo Pump PH2400 0-SH/P -2-Speed Hi-Flo Pump PH2500 0-SH/P -2-Speed Hi-Flo Pump PH2500 0-SH/P -2-Speed Hi-Flo Pump PH2500 0-SH/P -2-Speed Hi-Flo Pump PH	22	417-6241	1 ½" MPT x 1 ½" Male Smooth	24a				
24 672-7401 ClearWater II Base #10 x 1" 5/5 Phillips Head Screw (2) 2" Union Nut Coupling 2" Union Gasket (2) Snap Pin (4) 115 On 1 1 HP - 1-Speed Hi-Flo Pump PH1150 1½ HP - 1-Speed Hi-Flo Pump PH200 2 HP -1-Speed Hi-Flo Pump PH200 1 HP - 2-Speed Hi-Flo Pump PH200 1 HP -2-Speed Hi-Flo Pump PH200 2 HP -2-Speed Hi-Flo Pump PH200 6" Tap - 1½ Buttress x 2" Flange 6" Basket Assembly O-Ring 31 319-3230 6" Basket Assembly O-Ring 33 319-3260 6" Tap Lid 24a 24a 25					← 12			
24a 819-0044 #10 x 1" S/S Phillips Head Screw (2) 25 415-5001 2" Union Nut 26 419-7241 Coupling 27 711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1HP -1-Speed Hi-Flo Pump PH1200 2HP -1-Speed Hi-Flo Pump PH2150 1½ HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 6" Basket Assembly 30 310-6500 6" Trap - 1½" Buttress x 2" Flange 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 28 29 21 20 27 26 25 27 26 25 27 26 25 30 28 29 28			•	20	12			
25 415-5001 2" Union Nut Coupling 27 771-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1HP -1-Speed Hi-Flo Pump PH1200 2 HP -1-Speed Hi-Flo Pump PH2150 1½ HP -2-Speed Hi-Flo Pump PH2200 2 HP -2-Speed Hi-Flo Pump PH2200 2 HP -2-Speed Hi-Flo Pump PH2200 6" Trap - 1½" Buttress x 2" Flange 30 310-6500 6" Trap - 1½" Buttress x 2" Flange 31 319-3230 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 29 20 21 22 23 23 24 24a 24a 25 26 25 37 26 27 26 27 21 28 28								
26 419-7241 Coupling 27 711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1 HP - 1-Speed Hi-Flo Pump PH1200 2 HP - 1-Speed Hi-Flo Pump PH2100 1 HP - 2-Speed Hi-Flo Pump PH2200 2 HP - 2-Speed Hi-Flo Pump PH2200 2 HP - 2-Speed Hi-Flo Pump PH2200 2 HP - 2-Speed Hi-Flo Pump PH2200 6" Trap - 1 ½" Buttress x 2" Flange 31 319-3230 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 28 29 20 21 22 23 21 22 23 24 24 15 DETAIL 6a					13 ————————————————————————————————————			
711-4010 2" Union Gasket (2) 28 429-7221 Snap Pin (4) 29 PH1100 1HP -1-Speed Hi-Flo Pump PH1200 2HP -1-Speed Hi-Flo Pump PH2100 1HP -2-Speed Hi-Flo Pump PH2150 1½ HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 2HP -2-Speed Hi-Flo Pump PH2200 5HP -2-Speed Hi-Flo Pump PH2200 6" Trap -1 ½" Buttress x 2" Flange 31 319-3230 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 29 21 21 22 21 22 23 24 24 24 24 28 29					ň			
28				24a	13 → ← 16			
29 PH1100			• •					
PH1150 1½ HP - 1-Speed Hi-Flo Pump PH2100 2 HP - 1-Speed Hi-Flo Pump PH2100 1 HP - 2-Speed Hi-Flo Pump PH2150 1½ HP - 2-Speed Hi-Flo Pump PH2200 2 HP - 2-Speed Hi-Flo Pump PH2200 6" Trap - 1½" Buttress x 2" Flange 6" Basket Assembly 6 "Basket Assembly 2 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 28 29 21 21 22 23 27 21 26 28 29 28			•	DETAIL 63	17—			
PH2100 1 HP - 2-Speed Hi-Flo Pump PH2150 1½ HP - 2-Speed Hi-Flo Pump PH2200 2 HP - 2-Speed Hi-Flo Pump 30 310-6500 6"Trap - 1½" Buttress x 2" Flange 31 319-3230 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 28 29 21 21 22 23 24 24 28 29		PH1150		DETAIL 0a				
PH2100 THP - 2-Speed Hi-Flo Pump PH2200 2 HP - 2-Speed Hi-Flo Pump PH2200 30 310-6500 6" Trap - 1 ½" Buttress x 2" Flange 31 319-3230 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 21 21 22 23 24 24 24 24 28					18			
PH2200 2 HP - 2-Speed Hi-Flo Pump 30 310-6500 6" Trap - 1 ½" Buttress x 2" Flange 31 319-3230 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 28 29 21 20 27 21 20 22 27 21 28 29 29 20 20 20 20 20 20 20 20			·					
30					1 ← 19			
31 319-3230 6" Basket Assembly 32 805-0436 0-Ring 33 319-3260 6" Trap Lid 28 21 21 22 21 22 23 24 24 24 24 24 24 24 28	20			33	30 BA			
32 805-0436 O-Ring 33 319-3260 6"Trap Lid 28 27 21 21 26 25 25 28 29 29 29 29 29 29 29 29 29 29 29 29 29				∠	20			
33 319-3260 6" Trap Lid 28 21 30 28 21 30 28 24a 24a			·					
28 21 30 28 28 24a 28 29				32	8			
28 21 31 30 28 28 28 29			1		21 22			
28 29 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 29 28 29 29 29 29 28 29 29 29 29 29 29 29 29 29 29 29 29 29			28		125 / /			
28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 29 28 29 29 28 29 29 28 29 29 29 29 29 29 29 29 29 29 29 29 29			N	21	20			
28 29 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 28 29 29 28 29 29 29 29 29 29 29 29 29 29 29 29 29			*	31	1000			
28 29 29 28 29 29 28 29 29 29 29 29 28 29 29 29 29 29 29 29 29 29 29 29 29 29								
28 24a 29		21 23						
28 24a 29								
28 24a 29				79				
28	Ź		7/2	29				
	20		240	/				
DETAIL 4 DETAIL 6aa	20				24a (2)			
		DETAIL 4	DETAIL 6a	na	24			