

## **SWIM SPA & SWIM WORKOUT INSTRUCTIONS**



 Press the SWIM button to turn the pump ON – the blue SWIM icon on the LCD screen turns ON.



Swim Speed

1

2. Then press UP or DOWN button to select your desired SPEED #.

**3.** Press the **SWIM** button again to turn **OFF** the pump – the blue **SWIM** icon on the LCD screen turns **OFF**.



## **SWIM WORKOUT PROGRAMMING**

Rotate View
Special Temp
Heat Mode
Filter Cycles
Date-Time


1. To program the SWIM
WORKOUT; press the
MENU button; then UP
button and select SWIM
WORKOUT by pressing
the MENU button to get
to the WARM UP setting.

2. Press the UP or DOWN button to select the SPEED # for WARM UP; then press the MENU button to select DURATION in minutes; then press the MENU button twice to get to WORKOUT.



Swim Workout

Warm Up
Speed:
4
Duration:
20 Min >>



Warm Up
Speed:
4
Duration:
20 Min >>

## SWIM WORKOUT PROGRAMMING (continued from front)



3. Press the UP or DOWN button to select the SPEED # for **WORKOUT**; then press the **MENU** button to select **DURATION** in minutes: then press the **MENU** button twice to get to COOL DOWN.



4. Press the **UP** or **DOWN** button to select the SPEED # for **COOL DOWN**; then press the **MENU** button to select **DURATION** in minutes; then press the RETURN button twice to get out of SWIM WORKOUT.



**Swim Speed** 

5. Press the SWIM WORKOUT button to turn ON the pump – the red **SWIM** icon on the LCD screen turns ON. The WORKOUT feature will activate to cycle each of the SPEED setting and specific **DURATION** setting for **WORKOUT**. If you need to increase or decrease the pump speed manually; then press the **UP** or **DOWN** button to your desired **SPEED** # in each cycle.



6. Press the SWIM WORKOUT button again to turn OFF the pump - the red **SWIM** icon on the LCD screen turns OFF.



2200 E. Sturgis Rd., Oxnard CA 93030 Phone 805.981.0262 • Fax 805.981.9403 waterway@waterwayplastics.com • www.waterwayplastics.com