




2 1/2" POLY STORM GUNITE JET (210-3710) INSTALLATION INSTRUCTIONS AND PRESSURE TESTING




1. Hang Poly Storm Gunite Jet Body with ties through preset holes onto steel rebar.




2. Estimate needed length of 2 1/2" PVC pipe by thickness of wall. Cut 2 1/2" PVC pipe at least 4" longer than estimated finish length. Then glue 2 1/2" PVC pipe to body.




3. Glue 2 1/2" cap onto end of pipe for pressure test before guniting.




4. While guniting, scoop out gunite around the 2 1/2" PVC pipe, allowing for the plaster niche (425-5030) (not included). Before plastering, cut the 2 1/2" pipe so that the plastic niche will fit flush with the finished wall. Glue the plaster niche onto the pipe, then cover the niche with tape for plastering.




5. Cut a piece of 1" PVC pipe a couple of inches longer than the 2 1/2" pipe and glue the threaded retainer ring to it.



6. Insert 1" PVC pipe through the niche and up to the Poly Storm Gunite jet body and thread in until it bottoms out. Make a mark on the 1" PVC pipe flush with the gunite niche.



7. Unscrew 1" PVC Pipe from the body and cut 4 1/8" inward from the mark towards retainer ring, then glue wallfitting to 1" PVC pipe.




8. Wrap Teflon tape onto the threaded retainer ring and thread the 1" PVC pipe back into the body using a Poly Storm Gunite Wrench (218-1790), making sure of a snug fit.




2200 East Sturgis Road, Oxnard, CA 93030 • Ph. (805) 981-0262 • Fax (805) 981-9403


www.waterwayplastics.com • waterway@waterwayplastics.com



9. Always use at least one non-adjustable internal per spa to prevent deadheading pump.





10. Align tab behind escutcheon face with slot on wallfitting. Location of slot and tab are shown below. Push Poly internal into wallfitting until it snaps into place. To reduce water flow, turn clockwise. To increase water flow, turn counter-clockwise until it stops turning. To remove, continue turning counter-clockwise past stopping point. You will hear a snap to confirm release of Poly internal.




! To prevent personal injury, shock, or property/equipment damage, an Air Spring Check Valve (2" 600-8160, 1 1/2" 600-8140) must be installed on the blower stand pipe in case of a water backup in the air line.

NOTE: If a blower is not being used, please direct the air intake toward the ground using the 2" Sweep Vent Grate Assembly (400-4130) on the Air Inlet Pipe.




POLY STORM JET INTERNALS AND ACCESSORIES


! Always use at least one Non-Adjustable internal per spa to prevent deadheading pump.




Large Volume
212-8040G - White
17-20 GPM




Galaxy
212-8190G - White
10 GPM




Galaxy Massage
212-8530G - White
10 GPM




Power Storm II
212-8250G - White
10 GPM




Multi Massage
212-8270G - White
10 GPM




Twin Roto
212-8120G - White
10 GPM




Roto
212-8010G - White
10 GPM




Directional
212-8050G - White
10 GPM



Massage (7 Nozzle)
212-8030G - White
10 GPM



Wrench
218-1790



Handheld Jet
210-3250
10 GPM